




Half Scale Sections




EXPANDERS



2-3/8" PANNING EXPANDER
S-027




5" EXPANDER
S-984




7" EXPANDER
S-2100

Half Scale Sections


EXPANDERS




1/2" SILL EXPANDER
S-1955




EXTENDED CAULK STOP
S-1441




1-1/4" INTERIOR EXPANDER
S-1954




1-1/2" X 1-1/4" EXPANDER
S-445




2-1/4" EXPANDER
S-783




1-1/4" PANNING EXPANDER
S-1952



3/4" X 1/2" EXPANDER
S-1632




1-5/8" EXPANDER
S-1931




3-3/8" DUAL EXPANDER
S-1399


Half Scale Sections




2-3/4" X 1-3/4" EXPANDER
S-2960




1-3/4" EXPANDER
S-1680




1-1/4" EXPANDER
S-561




1-3/4" CASING EXTENSION
S-169




2-3/4" CASING EXTENSION
S-466




3/4" X 5/8" EXPANDER
S-2294



3/4" X 1/2" EXPANDER
S-2382




HEAD CAULK RETURN
S-2019




CAULK RETURN CLIP AND COVER
S-2021 & S-2020

Half Scale Sections




S-182

FOR USE WITH TR-5055 ONLY


5055 HEAD RECEPTOR
S-182


S-512

3-1/4" HEAD RECEPTOR
S-512



S-319

FOR USE WITH TR-9000

4" HEAD EXTENDER
S-319



S-626

FOR USE WITH TR-9000

FRAME INSERT
S-626



S-1250

FOR USE WITH TR-3000
SLIDE FIT WITH H-377


3-1/4" HEAD ADAPTER
S-1250


S-1413

FOR USE WITH TR-9100

9100 FRAME INSERT
S-1413


S-1388

3.25 X 1.375 HEAD ADAPTER
S-1388


S-1530

FOR USE WITH TR-5700

5600 HEAD EXPANDER
S-1530